


RS1 - PUSH BUTTON FLAT HEAD

RS2 - PUSH BUTTON PROTRUDING HEAD



**PUSH BUTTON PROTRUDING HEAD
RS2-**




RS3 - PUSH BUTTON MUSHROOM HEAD

RS4 - PUSH BUTTON LATCHING MUSHROOM




**PUSH BUTTON LATCHING MUSHROOM
RS4-**



RS5 - SELECTOR SWITCH SHORT HANDLE




**SELECTOR SWITCH SHORT HANDLE
RS5-**



RS6 - SELECTOR SWITCH LONG HANDLE



**SELECTOR SWITCH LONG HANDLE
RS6-**




RS7 - ILLUMINATED PUSH BUTTON FLAT HEAD

RS8 - ILLUMINATED PUSH BUTTON PROTRUDING



ILLUMINATED PUSH BUTTON PROTRUDING RS8-



CONTACT BLOCK & LAMP BLOCK

TYPE NO A-10

TYPE NO E-01

TYPE NO L-06



Địa chỉ: 10/10 Đường Nguyễn Huệ, Quận 1, TP. HCM
Số điện thoại: 0903 123 456